TOP AND CABINET PARTS

For Models: GHW9400PW0, GHW9400PL0, GHW9400PT0
(White/Platinum) (Pewter) (Biscuit)

AUTOMATIC
WASHER



Literature Parts

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CABINET PARTS

For Models: GHW9400PW0, GHW9400PL0, GHW9400PT0
(White/Platinum) (Pewter) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	8182276	Use & Care Guide
	8182277	Tech Sheet
	8182278	Energy Guide
	8182270	DVD−Instruction
	8182258	Dispenser Guide
	8182196	Quick Start Guide
2		Top
	8181641	White
	8182061	Pewter
	8181830	Biscuit
3		Cabinet
	8181630	White
	8182063	Pewter
	8181805	Biscuit
4		Panel, Front
	8181838	White
	8182060	Pewter
	8182059	Biscuit
5		Toe Panel
	8181643	White
	8182062	Pewter
	8181809	Biscuit
6	8181636	Foot, Leveling
7	8181763	Bracket, Spring
8	8181634	Brace, Side Panel
9	8181635	Pan, Bottom
10	8182118	Panel, Rear
11	8182117	Brace, Transport
12		Bolt, Shipping
	8182124	Upper
	8182125	Lower
13		Hose, Water Inlet
	8181706	Blue Coupler
	8181707	Red Coupler
14	8182120	Cord, Power
15	8181690	Strain Relief
16	8182116	Brace, Rear
17	8182209	Clip, Drain Hose
18	8181737	Drain Hose (Outer)
19	8181738	Connector, Drain Hose
20	8181752	Clamp, Hose
21	8181632	Brace, Top
22	8181683	Filter, Interference
23	8181695	Switch, Pressure
24	8181739	Hose, Pressure Switch
25	8181691	Screw
26	8182216	Cover, Transport
27	8181768	Storage, Hose
28	8181828	Screw
29	8181930	Microswitch (2)
30	8182200	Grommet, Cord Support (2)
31	8182201	Screw, 3 x 8 mm

Following Parts Not Illustrated

	8182109	Harness Channel

DOOR AND LATCH PARTS

For Models: GHW9400PW0, GHW9400PL0, GHW9400PT0
(White/Platinum) (Pewter) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR AND LATCH PARTS

For Models: GHW9400PW0, GHW9400PL0, GHW9400PT0
(White/Platinum) (Pewter) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
5	8182119	Bellow
6	8182210	Clamp, Bellow (Rear)
7	8181700	Lock, Door
8	8181760	Screw
9	8181651	Hook, Door
10	8181758	Screw
14	8182211	Clamp, Bellow (Front)
15	8181659	Clamp, Support
16	8181650	Clamp, Glass
17	8181785	Screw
20		Door Frame Asm
	8182044	Platinum
	8182086	Pewter
	8182087	Biscuit
21	8181655	Glass, Door
22		Door, Back Support
	8181849	For White & Biscuit Models
	8181658	For Pewter Models
23	8181843	Hinge, Door
24	8181660	Screw
25	8181661	Screw
26	8181718	Tube, Dispenser to Bellow
27		Trim, Upper Left
	8181842	Platinum
	8182078	Pewter
	8182079	Biscuit
28		Cover, Hinge (Outer)
	8181841	Platinum
	8182082	Pewter
	8182083	Biscuit
29		Cover, Hinge (Inner)
	8181844	Platinum
	8182074	Pewter
	8182075	Biscuit
30		Trim, Lower
	8181840	Platinum
	8182072	Pewter
	8182073	Biscuit
31		Handle, Door
	8181846	Platinum
	8182080	Pewter
	8182081	Biscuit
32	8181929	Clip, Trim
33		Trim, Upper Right
	8181839	Platinum
	8182076	Pewter
	8182077	Biscuit
34	8181759	Screw

CONTROL PANEL PARTS

For Models: GHW9400PW0, GHW9400PL0, GHW9400PT0
(White/Platinum) (Pewter) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: GHW9400PW0, GHW9400PL0, GHW9400PT0
(White/Platinum) (Pewter) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1		Panel, Control
	8182653	Platinum
	8182654	Pewter
	8182655	Biscuit
2	8182691	User Interface
3	8181860	Button, Power
4	8181861	Button, Start
5		Button Set, Soil Level
	8181863	Platinum
	8182052	Pewter
	8182053	Biscuit
6	8182275	Button, Pause/Cancel
7		Button Set, Options
	8181864	Platinum
	8182068	Pewter
	8182069	Biscuit
8		Button Set, Spin/Temperature
	8181865	Platinum
	8182054	Pewter
	8182055	Biscuit
13	8182224	Brace, Front Top
14	8181640	Channel, Water
15	8182280	Microcomputer, Machine Control
16	8181756	Screw
17	8182212	Harness, Wiring (Main)
19		Handle, Drawer
	8181854	Platinum
	8182070	Pewter
	8182071	Biscuit
20	8181855	Bezel, Knob
21	8181857	Overlay, Door
22	8181858	Medallion
23		Knob, Control
	8181859	Platinum
	8182050	Pewter
	8182049	Biscuit
24		Endcap, Left
	8181852	White
	8182064	Pewter
	8182066	Biscuit
25		Endcap, Right
	8181853	White
	8182065	Pewter
	8182067	Biscuit

DISPENSER PARTS

For Models: GHW9400PW0, GHW9400PL0, GHW9400PT0
(White/Platinum) (Pewter) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DISPENSER PARTS

For Models: GHW9400PW0, GHW9400PL0, GHW9400PT0
(White/Platinum) (Pewter) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	8181694	Valve, Inlet
2	8181710	Hose, Flowmeter (L−Shaped)
3	8181751	Clamp
4	8181696	Flowmeter
6	8181708	Hose, Flowmeter
7	8181713	Nozzle, Inlet
9	8181714	O−Ring
11	8181726	Cam, Actuator
12	8181725	Lever, Water Distribution
13	8181723	Actuator
14	8181759	Screw, Self−Cutting
15	8181727	Spring, Lever
16	8181724	Connection, Lever
17	8182122	Dispenser
18	8181712	Nozzle, Distribution
19	8181747	Seal
20		Handle, Drawer (Included with Control Panel)
	8181854	Platinum
	8182070	Pewter
	8182071	Biscuit
21	8181720	Drawer, Detergent
22	8181722	Container, Detergent
23	8181729	Siphon, Bleach/Softener
24	8181730	Separator
25	8181721	Hook, Drawer
26	8182123	Cap
27	8181781	Harness, Wiring (Inlet Valve)

TUB AND BASKET PARTS

For Models: GHW9400PW0, GHW9400PL0, GHW9400PT0
(White/Platinum) (Pewter) (Biscuit)



TUB AND BASKET PARTS

For Models: GHW9400PW0, GHW9400PL0, GHW9400PT0
(White/Platinum) (Pewter) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	8182132	Nut, Pulley
2	8181671	Pulley
3	8181670	Belt
4	8181745	Grid, Ventilation
5	8181744	Pipe, Ventilation
6	8181746	Clamp
7	8181743	Hose, Exhaust
8	8181666	Tub, Rear
9	8181644	Counterweight, Rear
10	8181673	Gasket, Tub
11	8182247	Basket
12	8182233	Baffle, Basket
13	8181748	O−Ring
14	8181731	Airtrap
15	8181645	Counterweight, Front (2)
16	8181762	Spring, Suspension
17	8181647	Bolt
18	8181742	Clamp
19	8181794	Hose, Tub to Dispenser
20	8181667	Clamp
21	8181665	Tub, Front
22	8181648	Nut, Push−In
23	8181646	Shock Absorber
24	8181686	Clamp, Heating Element
25	8181685	Element, Heating
26	8181705	NTC
27	8181687	Screw
Following Parts Not Illustrated		
	8182126	Screw, Baffle Mounting

PUMP AND MOTOR PARTS

For Models: GHW9400PW0, GHW9400PL0, GHW9400PT0
(White/Platinum) (Pewter) (Biscuit)



PUMP AND MOTOR PARTS

For Models: GHW9400PW0, GHW9400PL0, GHW9400PT0
(White/Platinum) (Pewter) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	8181693	Control Unit (Motor)
4	8181733	Ball
5	8181734	Clamp
6	8181732	Hose, Tub to Pump
7	8181753	Clamp
8	8181786	Damper, Rubber (Rear)
9	8181752	Clamp
10	8181684	Pump (Complete)
11	8181787	Damper, Rubber (Front)
12	8181780	Screw
13	8181736	Seal, Filter Cap
14	8181735	Cap, Filter
15	8181766	Cover, Motor
16	8181682	Motor
17	8181782	Harness, Motor
18	8181761	Bolt, Motor
19	8181755	Retainer, Drain Hose
20	8181740	Drain Hose (Inner)
21	8181757	Screw

OPTIONAL PARTS (NOT INCLUDED)

For Models: GHW9400PW0, GHW9400PL0, GHW9400PT0
(White/Platinum) (Pewter) (Biscuit)

Illus. No.	Part No.	DESCRIPTION

PAINT, TOUCH−UP (1/2oz.)

72017	White
4396174	Pewter
4392899	Biscuit

PAINT, PRESSURIZED SPRAY (12 oz.)

350938	Primer, Gray
350930	White
4396175	Pewter
4392901	Biscuit

PAINT, BULK (1 qt.)

799344	White (Uncut)
4392900	Biscuit (Uncut)

ACCESSORY PARTS

285863	Drain Extension